

## AGRIPPA ACOUSTIC DIGITAL PILLOW ALARM

- NO INSTALLATION
- PORTABLE DEVICE
- TWO PRESET TRIGGER LEVELS PLUS ALARM LEARNING FUNCTION
- FLASHING WHITE LED VISUAL WARNING
- BUILT IN CLOCK WITH WAKE-UP ALARM
- VISUAL LOW BATTERY WARNING
- LCD BACK LIGHT DISPLAY
- STYLISH BEDSIDE DESIGN

listens & vibrates



The Agrippa pillow alarm is a battery powered, wire-free unit with a pad attachment that simply goes under a pillow. It uses digital wire-free technology that listens for the unique sound of a specific fire alarm.

If the fire alarm sounds the pillow pad vibrates, high intensity LED lights flash and an LCD screen displays 'fire'. As it's compact and portable it can be moved around a building as required.

The Agrippa pillow alarm is the convenient solution to cater for the safety of the deaf and hard of hearing as required by the Equality Act.

Ideally suited to environments such as hotels and hospitals where it is essential to alert the deaf or hard of hearing when a fire alarm is sounding.

The pillow alarm is part of the Agrippa suite of products, which also includes an acoustically triggered fire door closer and holder.

### TECHNICAL INFORMATION

Battery type	4 x AA batteries
Default setting	70dB - 75dB, 1.2 - 3.0 kHz
Preferred sounder	Continuous tone *
Dimensions	L-120 x W-120 x D-90
Standard finish	White
Part number	3-80-0045
Weight	380g

\* Not suitable for voice alarm systems

